

Fig. 1






FIG. 2



System Behavior State Flow Diagram

Fig. 3



Transmitter Behavior State Flow Diagram

FG. 4

5027 504 memore 506 519 LINK Software INTERFACE HO WETWORK con megisty MODULE Power MODE CONTROL ~50B MODULE PRIOR ART FIG. 5